



Split Electric Boosted Solar Hot Water Rough In Diagram (Left Hand Install Only)

